

## Polished Mustang Stainless Steel Radiator Cover - 2 Row (86-93) - Installation Instructions

---



The below installation instructions work for the following products:

- **Polished Mustang Stainless Steel Radiator Cover - 2 Row (86-93)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

### Installation:

1. Be sure your engine is turned off and cooled down.
2. Loosen the top two screws that hold your radiator shroud to the support.
3. Carefully, slip the one edge of the new radiator cap stainless cover between the radiator shroud and the support and retighten the two screws. This will secure the radiator cap stainless cover in place.
4. To clean this polished stainless cover use windex and a soft cotton cloth.

Installation instructions provided by Manufacturer

Find more **how-tos, instructions** and **videos** at [www.americanmuscle.com](http://www.americanmuscle.com)!