

Mustang White A/C Gauge Face (94-04) - Installation Instructions



The below installation instructions work for the following products:

- Mustang White A/C Gauge Face (94-00)
- Mustang White A/C Gauge Face (01-04)



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Start by turning each knob so they're all pointing up. Remove the three knobs by pulling them towards you.



2. Take your new gauge face and remove the backing to expose the adhesive.



3. Only one side will fit in at a time. Start by sliding the top of the gauge face up into the bezel far enough that the bottom of the face will clear the bottom of the bezel. Then line up the holes and press firmly to adhere.



4. Reinstall the knobs and enjoy your new AC gauge face!



Installation instructions provided by Manufacturer

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!