

5-Speed Shift Knob 1996-2004

41067
24018
41004
41235
102254
102253
41003
41430
41438
41433
41439



Remove the factory shift knob by rotating it counter clockwise.



Install the supplied nut. This nut is used to align the shift pattern on the shift knob. Thread the shift knob on until it is tight against the nut. If the shift pattern does not line-up simply adjust the nut up or down until it does. ****Note:** Ensure the reverse lockout is still functional. If not, loosen the lock nut and knob until it does.

