

FOOSE

Floor Mats 2015-2017



Remove the factory floor mats by lifting the rear edge and pulling upward. **Note: If your floor mats are clipped in from the factory, unclip them to remove them.



Vacuum the carpet before installing the new floor mats to prevent the new floor mat from grinding any dirt into the carpet.



Install the Foose floor mats, the large mats are for the front and the small mats are for the rear. Ensure the floor mat doesn't interfere with the operation of the vehicle's pedals. If there is interference move the floor mat backward.