

Auxiliary Radiator Tank

Contents:

- (1) Radiator Tank
- (1) Radiator Tank Cap w/ O-ring

Required:

- Manufacturer Approved Coolant
- Pliers
- 10mm Socket and Ratchet

Step 1:

Ensure the engine is cold prior to working on the cooling system. Failure to do so can result in injury.

Step 2:

Place coolant tray under the vehicle to catch any coolant that leaks out of the system during the installation of the Radiator Tank. **Dispose of used coolant correctly.

Step 3:

Remove various coolant hoses running to the factory radiator tank. **Note: All coolant hoses will get re-connected to the new tank. Remove the (2) 10mm bolts securing the factory coolant tank to the radiator and remove the tank from vehicle.

Step 4:

Install the new tank to the radiator using the factory bolts removed in step 3. Connect the coolant hoses removed in Step 3 to the new coolant tank. Top off the coolant system with manufacture approve engine coolant and check for leaks. Let the vehicle reach operating temperature and ensure the coolant level is "full".